


PALLET RACKING RELOCATION



YOU'VE DECIDED TO MOVE but how do you reconfigure the entire contents of your warehouse without delays or loss of productivity?



We take care of everything

Pallet Racking Solutions end-to-end de-installation and warehouse relocation service will make moving your pallet racking and storage handling equipment as painless as possible. We'll dismantle your current system, transport your racking nationwide, then set it up again in your new warehouse.

What's involved in a warehouse move?

- **Step 1: Visit current location.** We determine the size and the scope of the project and understand your warehouse work flow and what you want to achieve by the move.
- **Step 2: Visit new premises.** We establish how to best maximise the usable storage space and create time efficiencies. Part of the process is to ensure the soil class, concrete floor specifications and seismic zone of the new warehouse are all taken into account in the new design. As well as the loading weights on beams and frames and the integrity of your existing racking.
- **Step 3: Pallet racking plan.** All of the above factors are worked through by our designers and engineers and translated into a new pallet racking plan for your team's approval.
- **Step 4: Consenting process.** We start the consenting process with a PS1 Producer Statement. To understand more about what's involved see our comprehensive consenting process.
- **Step 5: De-installation.** We organise the move and start the de-installation of the racking. This can be done in stages to ensure that your warehouse is functional throughout the process.
- **Step 6: Transport.** Once the first of the racking is down it can be moved directly to the new premises. PRS can project manage the transport to ensure everyone is working to the same time frames.
- **Step 7: Installation.** Our crew will be on hand to receive the racking and start the re-installation in accordance with the approved plans. This process can be repeated several times (including after hours and weekend work if necessary) until all the racking is moved into its new home.
- **Step 8: Restoration.** With all the racking gone we can then remove the screw anchors and restore your old warehouse floor to its original condition if necessary.

Relocating or expanding within your existing facility

If you're relocating within your existing facility, there are a number of ways you can increase your pallet storage capacity, including:

- **Considering a narrow aisle option.** Standard counterbalance material handling equipment often needs 3.5m, or greater aisle widths. However, Narrow Aisle Material Handling equipment can reduce this to 1.8m or less, effectively doubling your pallet storage capacity in the same location!
- **Increasing the height** of your existing racking with structurally sound splicing that can be consented by council.
- **Selecting a new racking installation** including an increased number of frames and/or beams and higher frame options.

Find the solution that suits you

It doesn't have to be PRS racking that's being moved, our team is familiar with all the products on the market.

PRS also buy and sell second-hand racking, so if you find there's some racking that no longer suits your needs we can buy it off you. And of course, we can help provide you with any additional new or second-hand racking or shelving for your new warehouse.

Moving house is stressful enough never mind an entire warehouse. Let us take care of it for you. Save time, stress and money – call Pallet Racking Solutions today.

WHY PRS? We're a proudly NZ owned and operated company. We build better businesses by solving storage problems nationwide. If you're looking for experienced storage advice, quality products, service and installation – our team's here to help.

AKL 09 239 1601 | TRG 07 220 9280 | CHC 03 972 5320
www.prs.co.nz | sales@prs.co.nz

